



# Quick Start Procera® Prep Guide

## Anterior




For best results with Procera® restoration, the prep design should allow access for *the scanning probe*. (see image on the left)


Use a conventional all-ceramic preparation design consisting of a chamfer or a rounded shoulder type design.




Place three orientation depth grooves using Brasseler bur 6878K-021. ③




Connect the orientation grooves together. ③




Reduce of the incisal surface approximately 2mm. Use the tip of the 6878K-021 burr as a guide. ③



A two plane preparation allows for correct and sufficient tooth reduction. ③




Reduce cingulum area, reassuring the same quality of preparation established on the facial surface. ③




Break the mesial and distal contact area. Avoid infringing on the biologic width. ② ③



Reduce incisal and central third of the tooth reassuring an ideal lingual clearance. Round off all sharp corners. ④



Refine and smooth the chamfer upward a distance of 0.5mm into the sulcus. ③ ②



Step 1.  
Step 2.  
Step 3.  
Step 4.

- Avoid "J" shaped preparation margin
- Avoid sharp-ended or butt margin
- Avoid one-plane facial tooth reduction

② ③ ④



**Additional information obtained from Procera®/ Brasseler CD on Preparation Techniques**